




spare parts list Junio-Stripper 230V EU



Table of contents

3 Junio Stripper (001/2003-0815/2006)	3
1 Machine	5
1 Motor 230V see 165921	7
2 Circuit Diagram	10
3 Tool kit	12
4 Accessory	14
4 Junio Stripper (0816/2006 - 04309/2021)	15
1 Machine	17
1 Motor 230V see 165921	19
2 Circuit Diagram	22
3 Tool kit	24
4 Accessory	26
5 Junio Stripper (04310/2021 - heute)	27
1 Machine	29
1 Motor green L125 230V/50-60Hz/1200W	31
2 Machine Special handle	34
1 Motor green L125 230V/50-60Hz/1200W	36
3 Circuit Diagram	39
4 Tool kit	41
5 Accessory	43


3 Junio Stripper (001/2003-0815/2006)



3 Junio Stripper (001/2003-0815/2006)

Item no.	Article no.	Description
1	03_01_016876	Machine
2	01_03_016927	Circuit Diagram
3	01_04_016876	Tool kit
4	01_05_016876	Accessory


1 Machine



1 Machine

Item no.	Article no.	Description	Quantity
1	019532	Motor 230V see 165921	
2	017921	Adapter flange Junio	1
3	017586	Bearing plate new HS 800/Junio	1
4	017884	Excentric plate	1
5	015187	Striking foot Junio	1
6	014703	Ball-bearing 6004	1
7	014929	Rubber bearing Junio Stripper	4
8	014859	Schnorr washer M6	3
9	014728	Cylinder head screw M6x14 DIN 6912	3
10	014747	Safety screw M6x10	11
11	013998	Spare blades 120 mm x 1,0 mm	1
12	017888	Handle Handstripper Junio	1
13	014923	Grip cover/foam	2
14	014752	Cylinder head screw M6x20DIN 912 microve	1
15	017725	Cylinder head screw M4x20 DIN 912	4
16	017949	Knurled bush	1
17	015317	Blade protection 135mm	1
o.Abb.	059185	Plug adapter 2-pole 230V CH T11	1
o.Abb.	073312	Adapter Plug 2-pol.230V SK2 UK/Euro	1
o.Abb.	084419	Plug 3-pole Heavy Duty 10A AUS	1

1 Motor 230V see 165921




1 Motor 230V see 165921

Item no.	Article no.	Description	Quantity
30	019452	Gear shaft Flex Junio03	1
31	015171	Bearing HK 0810	1
32	018088	shim ring	1
33	019454	O-Ring 48x1,2	1
34	018757	Spacer 0,2L Flex Junio03	1
36	019455	Sealing ring Flex Junio03	1
37	019456	Gear shaft inst. Flex Junio03	1
38	018048	Screw KT Flex Junio 03	2
39	018019	screw KT Flex Junio03	4
40	019457	Locking stud Flex Junio03	1
41	019458	Pressure spring 9x14,5x0,6	1
42	019459	O-Ring 12,42x1,78	1
43	018670	Hexagon nut M7	1
44	019460	Pinion Flex Junio03	1
45	019461	Bushing	1
46	019462	Sealing bushing Flex Junio03	1
47	017001	Ball Bearing 6000 2RSH	1
48	019463	Bearing cover Flex Junio03	1
49	019464	Air guide	2
51	019465	Wing Flex Junio03	1
52	019466	Armature 230V Flex Junio03/Piranha	1
53	014642	ZZZBall bearing 607 2RS C3ZZZ	1
54	019266	Bearing ring Combi Stripper /Junio 03	1
55	019468	Air circulation Flex Junio03	1
56	018049	Screw Flex Junio 03	2
57	019469	Braid f.capacitor	1
58	019470	Magnetic field 230V Flex Junio03/Piranha	1
59	018634	Motor housing Flex Junio03	1
60	015182	Shift lever Junio03,Kombi	1
61	015181	Shifter rod Junio03,Kombi	1
62	019473	Pressure spring 6,2x28x0,5	1
63	015177	Switch (shifter)Kombi-Str./HS500/HS800/J	1
64	015176	Condenser 230V Kombi	1
65	019476	Cable clamb cpl. 230V Flex Junio03	1

1 Motor 230V see 165921


Item no.	Article no.	Description	Quantity
66	018050	Screw Flex Junio 03	1
67	015178	Carbon brush 230V/120V Kombi-Str.	1
68	015179	Cable casing Kombi (in motorhousing}	1
69	018644	Cover Wolff Junio-Stripper	1
70	018039	Screw KT4x12 Motor Duro 2.0	2
71	015215	Cable 2x1 ² x4m black w.plug	1

2 Circuit Diagram



2 Circuit Diagram

3 Tool kit




3 Tool kit

Item no.	Article no.	Description
1	013998	Spare blades 120 mm x 1,0 mm
2	015317	Blade protection 135mm
3	033199	Measurer bag Junio
4	017612	Double fork wrench sw10/13 mm
5	015809	Safety gloves 1 pair
6	015315	Hearing protectors

4 Accessory

Item no.	Article no.	Description	Quantity
1	013342	Carpet clamp Premium	1
2	013934	Floor scraper SEE 34543	1
3	013998	Spare blades 120 mm x 1,0 mm	1
4	014000	Spare blades, 200 mm x 1,0 mm	1
5	015519	ZZSpare blades f. Combi-Stripper, 135 mm	1
6	033199	Measurer bag Junio	1
7	051505	Hand scraper WOLFF	1
8	062700	Ergo Cutter	1
9	065500	Profi hand sraper Wolff	1


4 Junio Stripper (0816/2006 - 04309/2021)



4 Junio Stripper (0816/2006 - 04309/2021)

Item no.	Article no.	Description
1	03_01_016876	Machine
2	01_03_016927	Circuit Diagram
3	01_04_016876	Tool kit
4	01_05_016876	Accessory


1 Machine



1 Machine

Item no.	Article no.	Description	Quantity
1	040994	Motor 230V see 165921	
2	017921	Adapter flange Junio	1
3	017586	Bearing plate new HS 800/Junio	1
4	017884	Excentric plate	1
5	015187	Striking foot Junio	1
6	014703	Ball-bearing 6004	1
7	014929	Rubber bearing Junio Stripper	4
8	014859	Schnorr washer M6	3
9	014728	Cylinder head screw M6x14 DIN 6912	3
10	014747	Safety screw M6x10	11
11	013998	Spare blades 120 mm x 1,0 mm	1
12	017888	Handle Handstripper Junio	1
13	014923	Grip cover/foam	2
14	014752	Cylinder head screw M6x20DIN 912 microve	1
15	017725	Cylinder head screw M4x20 DIN 912	4
16	017949	Knurled bush	1
17	015317	Blade protection 135mm	1
o.Abb.	059185	Plug adapter 2-pole 230V CH T11	1
o.Abb.	073312	Adapter Plug 2-pol.230V SK2 UK/Euro	1
o.Abb.	084419	Plug 3-pole Heavy Duty 10A AUS	1

1 Motor 230V see 165921




1 Motor 230V see 165921

Item no.	Article no.	Description	Quantity
1	041108	Locking button cpl. Flex Junio07	1
2	019458	Pressure spring 9x14,5x0,6	1
3	019459	O-Ring 12,42x1,78	1
4	018019	screw KT Flex Junio03	1
5	018048	Screw KT Flex Junio 03	1
6	041109	Gear block housing Flex Junio07	1
7	015171	Bearing HK 0810	1
8	041141	Distance ring Flex Junio07	4
9	019454	O-Ring 48x1,2	1
10	018757	Spacer 0,2L Flex Junio03	1
11	017725	Cylinder head screw M4x20 DIN 912	4
12	019455	Sealing ring Flex Junio03	1
13	041144	Gear shaft inst. Flex Junio06	1
14	019464	Air guide	1
15	019462	Sealing bushing Flex Junio03	1
16	041145	Pinion Flex Junio07	1
17	041147	Ball bearing Flex Junio 07	1
18	019463	Bearing cover Flex Junio03	1
19	041096	Armature 230V Flex Junio06	1
20	041146	Ball bearing 607-2RS Flex Junio 07	1
21	019465	Wing Flex Junio03	1
22	019266	Bearing ring Combi Stripper /Junio 03	1
23	018049	Screw Flex Junio 03	1
24	019468	Air circulation Flex Junio03	1
25	041099	Magnetic field 230V Flex Junio06	1
26	018634	Motor housing Flex Junio03	1
27	018039	Screw KT4x12 Motor Duro 2.0	1
28	041149	Elektronic 230V Flex Junio06	2
29	015182	Shift lever Junio03,Kombi	1
30	015181	Shifter rod Junio03,Kombi	1
31	019473	Pressure spring 6,2x28x0,5	2
32	015177	Switch (shifter)Kombi-Str./HS500/HS800/J	2
33	015179	Cable casing Kombi (in motorhousing}	1
33	019488	Rubber sleeve 115V	1

1 Motor 230V see 165921


Item no.	Article no.	Description	Quantity
34	018644	Cover Wolff Junio-Stripper	1
35	018039	Screw KT4x12 Motor Duro 2.0	1
36	015215	Cable 2x1 ² x4m black w.plug	1
37	019476	Cable clamb cpl. 230V Flex Junio03	1
38	018050	Screw Flex Junio 03	1
39	015178	Carbon brush 230V/120V Kombi-Str.	1

2 Circuit Diagram



2 Circuit Diagram

3 Tool kit




3 Tool kit

Item no.	Article no.	Description
1	013998	Spare blades 120 mm x 1,0 mm
2	015317	Blade protection 135mm
3	033199	Measurer bag Junio
4	017612	Double fork wrench sw10/13 mm
5	015809	Safety gloves 1 pair
6	015315	Hearing protectors

4 Accessory

Item no.	Article no.	Description	Quantity
1	013342	Carpet clamp Premium	1
2	013934	Floor scraper SEE 34543	1
3	013998	Spare blades 120 mm x 1,0 mm	1
4	014000	Spare blades, 200 mm x 1,0 mm	1
5	015519	ZZSpare blades f. Combi-Stripper, 135 mm	1
6	033199	Measurer bag Junio	1
7	051505	Hand scraper WOLFF	1
8	062700	Ergo Cutter	1
9	065500	Profi hand sraper Wolff	1


5 Junio Stripper (04310/2021 - heute)



5 Junio Stripper (04310/2021 - heute)

Item no.	Article no.	Description
1	05_01_016876	Machine
2	05_01_016152	Machine Special handle
3	01_03_016927	Circuit Diagram
4	01_04_016876	Tool kit
5	01_05_016876	Accessory


1 Machine



1 Machine

Item no.	Article no.	Description	Quantity
1	162797	Motor green L125 230V/50-60Hz/1200W	1
2	010336	Adapterflansch Akku Junio L125-18.0V	1
3	017586	Bearing plate new HS 800/Junio	1
4	010349	Eccentric disc Akku Junio L125-18.0V	1
5	015187	Striking foot Junio	1
6	014703	Ball-bearing 6004	1
7	014929	Rubber bearing Junio Stripper	4
8	014859	Schnorr washer M6	5
9	014728	Cylinder head screw M6x14 DIN 6912	3
10	014747	Safety screw M6x10	11
11	013998	Spare blades 120 mm x 1,0 mm	1
12	017888	Handle Handstripper Junio	1
13	014730	Cylinder head screw M 6x20 DIN 912	2
14	017725	Cylinder head screw M4x20 DIN 912	4
15	015317	Blade protection 135mm	1
16	016961	Snorr washer M4	4
18	014923	Grip cover/foam	1
o.Abb.	059185	Plug adapter 2-pole 230V CH T11	1
o.Abb.	073312	Adapter Plug 2-pol.230V SK2 UK/Euro	1
o.Abb.	084419	Plug 3-pole Heavy Duty 10A AUS	1

1 Motor green L125 230V/50-60Hz/1200W



162797 Motor L125 230V/50-60Hz/1200W


1 Motor green L125 230V/50-60Hz/1200W

Item no.	Article no.	Description	Quantity
1	015248	Tension nut LS 35 SEE 082245	1
2	159339	Clamping flange L125-18V	1
3		Nut L 10-10 125	1
4	170832	Pinion L 10-10 125	1
5		Spring L 10-10 125	1
6		Rubber damper	2
7		Screw M3x6	2
8	159337	Protection cover Ø125mm L125-18V	1
9		Handle GS-K/II M8	1
10		Screw M4x15	4
11		Cable fixation	1
12	159328	Switch button L125-18V	1
13		Shaft washer	1
14		Screw	2
15		Screw	4
16	159273	Screw ST4 2x22 L125-18V	4
17		Gearbox compl.	1
18	166177	Gear shaft mount. L10-11 125	1
19		Armature compl.	1
20	173976	Elektronic Motor L12-11 125	1
21	166178	Gasket gear shaft L10-11 125	1
22		Carbon holder	2
23		Spring, spiral	2
24		Motor housing	1
25	173047	Seal kit switch cabinet Independence	2
26		Switch rod	1
27		Magnetic field	1
28		Air duct	1
29		Cable protection slot	1
30		Connection terminal	2
31		Switch	1
32		Key, face hole	1
33	015215	Cable 2x1 ² x4m black w.plug	1
34		Rating plate	1

1 Motor green L125 230V/50-60Hz/1200W

Item no.	Article no.	Description	Quantity
35		Brand plate	1
36	159563	Engine hood wolf green for L125 motors	1


2 Machine Special handle



2 Machine Special handle

Item no.	Article no.	Description	Quantity
1	162797	Motor green L125 230V/50-60Hz/1200W	1
2	010336	Adapterflansch Akku Junio L125-18.0V	1
3	017586	Bearing plate new HS 800/Junio	1
4	010349	Eccentric disc Akku Junio L125-18.0V	1
5	015187	Striking foot Junio	1
6	014703	Ball-bearing 6004	1
7	014929	Rubber bearing Junio Stripper	4
8	014859	Schnorr washer M6	3
9	014728	Cylinder head screw M6x14 DIN 6912	3
10	014747	Safety screw M6x10	11
11	013998	Spare blades 120 mm x 1,0 mm	1
12	017725	Cylinder head screw M4x20 DIN 912	4
13	015317	Blade protection 135mm	1
14	016961	Snorr washer M4	4
15	165100	Handle holder for Junio stripper S005	1
16	081258	Anti-vibration handle, M 8 black	2
17	014860	Schnorr Washer M8	2
18	017651	Cylinder head screw M8x16 DIN 912	2
o.Abb.	059185	Plug adapter 2-pole 230V CH T11	1
o.Abb.	073312	Adapter Plug 2-pol.230V SK2 UK/Euro	1
o.Abb.	084419	Plug 3-pole Heavy Duty 10A AUS	1

1 Motor green L125 230V/50-60Hz/1200W



162797 Motor L125 230V/50-60Hz/1200W


1 Motor green L125 230V/50-60Hz/1200W

Item no.	Article no.	Description	Quantity
1	015248	Tension nut LS 35 SEE 082245	1
2	159339	Clamping flange L125-18V	1
3		Nut L 10-10 125	1
4	170832	Pinion L 10-10 125	1
5		Spring L 10-10 125	1
6		Rubber damper	2
7		Screw M3x6	2
8	159337	Protection cover Ø125mm L125-18V	1
9		Handle GS-K/II M8	1
10		Screw M4x15	4
11		Cable fixation	1
12	159328	Switch button L125-18V	1
13		Shaft washer	1
14		Screw	2
15		Screw	4
16	159273	Screw ST4 2x22 L125-18V	4
17		Gearbox compl.	1
18	166177	Gear shaft mount. L10-11 125	1
19		Armature compl.	1
20	173976	Elektronic Motor L12-11 125	1
21	166178	Gasket gear shaft L10-11 125	1
22		Carbon holder	2
23		Spring, spiral	2
24		Motor housing	1
25	173047	Seal kit switch cabinet Independence	2
26		Switch rod	1
27		Magnetic field	1
28		Air duct	1
29		Cable protection slot	1
30		Connection terminal	2
31		Switch	1
32		Key, face hole	1
33	173417	Connection cable motor L125 H07 RN-F	1
34		Rating plate	1

1 Motor green L125 230V/50-60Hz/1200W


Item no.	Article no.	Description	Quantity
35		Brand plate	1
36	159563	Engine hood wolf green for L125 motors	1

3 Circuit Diagram



3 Circuit Diagram

4 Tool kit



4 Tool kit

Item no.	Article no.	Description	Quantity
1	013998	Spare blades 120 mm x 1,0 mm	1
2	015317	Blade protection 135mm	1
3	033199	Measurer bag Junio	1
4	017612	Double fork wrench sw10/13 mm	1
5	015809	Safety gloves 1 pair	1
6	015315	Hearing protectors	1
7	017806	Technical instructions Junio Stripper DE	1
8	017805	Technical instructions Junio Stripper So	1

5 Accessory

Item no.	Article no.	Description	Quantity
1	013342	Carpet clamp Premium	1
2	013934	Floor scraper SEE 34543	1
3	013998	Spare blades 120 mm x 1,0 mm	1
4	014000	Spare blades, 200 mm x 1,0 mm	1
5	015519	ZZSpare blades f. Combi-Stripper, 135 mm	1
6	033199	Measurer bag Junio	1
7	051505	Hand scraper WOLFF	1
8	062700	Ergo Cutter	1
9	065500	Profi hand sraper Wolff	1
10	010758	Carrying case midi3 SEE 171220	1
11	010663	Insert Systainer Junio-Stripper 18V	1
12	017806	Technical instructions Junio Stripper DE	1