



spare parts list Bodenschleifmaschine ALPHA




Table of contents

1 Concrete grinding ALPHA (07/2005 - heute)	3
1 Machine	4
1 Tools	6

1 Concrete grinding ALPHA (07/2005 - heute)


Item no.	Article no.	Description
1	01_01_037606	Machine
1	01_02_037606	Tools

1 Machine



1 Machine

Item no.	Article no.	Description
1		grinding tool
3		casting shaft
5		Rear Wheel
7		Bracket for Coupling
9	042689	Rubber coupling for drive Neo 230/Omega
11	051207	Disk admission for segments Alpha
13	053306	Sealing Alpha
15	059781	Screw for cover
17	053305	Ring plastic f.dust Alpha
19	066796	Motor NEO 230 2 KW EMG
19		Motor
21		Handle base
23	054564	Handle Top Alpha compl.
25	068030	Screw M10x25 Alpha
27	053303	Switch 230V Alpha
29		Grip covering
51	033120	Dia segment red
51	033846	Dia-segment silver
51	034282	Dia-segment PKD
o.Abb.	053225	Van cover
o.Abb.	071896	Screw Kid for Van Cover
o.Abb.	053305	Countersink bolt
o.Abb.	061296	Washer
o.Abb.	073235	Dust seal compl.
o.Abb.	071896	Screw set, van cover
o.Abb.	053304	Holdig device condenser
o.Abb.	034028	Condenser
o.Abb.	064194	Spirit level
o.Abb.	062417	Motor Protector



1 Tools

Item no.	Article no.	Description
7		Bracket for Coupling
9	042689	Rubber coupling for drive Neo 230/Omega
11	051207	Disk admission for segments Alpha
51	033120	Dia segment red
51	033846	Dia-segment silver
51	034282	Dia-segment PKD